


SPC Gear Viro Plus USB




BEFORE INSTALLING THE SOFTWARE, PERFORM THE SOUND CARD UPDATE

1. Connect the VIRO PLUS rev. 1.1 sound card to the USB port.
2. Run "CM1xx.exe" from "VIRO Plus Burn Tool (V1.0.0.2)" folder.
3. After a few seconds, the 'update completed' message will appear.



4. Disconnect the card, click 'OK' and then 'X' to close the program.
5. Everything is ready - now you can reconnect the card.










SPC Gear Viro Plus USB



SOFTWARE SETUP


1. To install the software, run the "Setup.exe" tool from "VIRO Plus (V1.0.1)" folder and follow the manual. Reboot the computer.




SPC Gear Viro Plus USB

SPEAKERS FUNCTIONS

▲ PROFILES




1. Switch to profiles view.
2. Main profile.
3. Saved user profiles.
4. Icons:
 - "+" add a new profile (to add a new profile, first change any setting other than the volume),
 - "-" remove the profile (main profile marked as Hi-Fi cannot be deleted).
5. Right-click (RMB) to expand the menu with available playback settings.
6. Click to select / deselect. When checked, VIRO PLUS is set as the default system playback device.
7. Right-click (RMB) to expand the menu with available microphone settings.
8. Click to select / deselect. When checked, VIRO PLUS is set as the system's default audio recording device.



SPC Gear Viro Plus USB

SPEAKERS FUNCTIONS


▲ VOLUME CONTROL



1. Master volume adjustment slider.
2. Left/right channel volume adjustment sliders.
3. 'Mute playback' button.
4. Click to lock or unlock the padlock. When unlocked, both sliders (left/right) can be adjusted separately.

▲ SAMPLE RATE


Selectable audio sampling rate: 44.1 or 48 KHz.



SPC Gear Viro Plus USB

SPEAKERS FUNCTIONS



EQUALIZERS



1. Click to turn the qualizer on/off.
2. Sliders for changing the gain of individual frequencies.
3. EQ presets.
4. A tool for creating your own EQ profiles.

To create your own profile ("MANUAL"), first choose one of the presets available (we recommend the "DEFAULT", in which all the sliders are set to "0"), then use the sliders to adjust the sound to your preferences. To save the profile, first enter its name in the box (*Please input preset name) and click the floppy disk icon (save).


Once added, your profiles are shown in the drop-down list. To choose one of them, just select it from the list.




SPC Gear Viro Plus USB

SPEAKERS FUNCTIONS

▲ ENVIRONMENT EFFECTS




1. Click to enable or disable the effects.
2. Select a predefined mode from the list to activate it.
3. Four of the available modes can also be activated by clicking the appropriate icon.
4. Click to activate the small / medium / large room effect.



SPC Gear Viro Plus USB








SPEAKERS FUNCTIONS


▲ 7.1 VIRTUAL SPEAKER SHIFTER



1. Click to enable or disable the feature.

2. Icons:


-  - Turn on the surround sound rotation clockwise,
-  - Turn on the surround sound rotation counterclockwise,
-  - Stop rotation at the current position,
-  - Activate the 'hand' to be able to manually move the speakers,
-  - Reset to default settings,
-  - "+" - increase the overall volume of the sound,
-  - "-" - decrease the overall volume of the sound.



SPC Gear Viro Plus USB

SPEAKERS FUNCTIONS



▲ XEAR SINGFX



1. Enable/disable the Key Shifting function (lowering/raising the pitch).
2. Adjustment sliders.
3. Enable/disable the Vocal Fading function (mutes the vocals).
4. Adjustment sliders.

▲ XEAR SURROUND MAX


You must first turn on the 7.1 surround sound to enable this feature.
This feature enhances the surround sound effect even further.



SPC Gear Viro Plus USB

MICROPHONE FUNCTIONS

VOLUME CONTROL



1. Enable / disable the Microphone Boost mode.
2. Adjust the volume of the recorded sound.
3. Mute recording.
4. The "Monitor" feature is disabled by default. Turning it on makes us hear "live" in the headphones what our microphone registers.

SAMPLE RATE


Selectable audio sampling rate: 44.1 or 48 KHz.



SPC Gear Viro Plus USB

MICROPHONE FUNCTIONS

XEAR SINGFX



1. Enable/disable and set the echo effect strength for the recorded sound.

NOISE REDUCTION

Enable/disable and set the background noise reduction level.

